



**MATERIALS**

1/8" Thick Hardboard

[Lowe's](#) #15483

or

[Home Depot](#) #7005015

**ALT MATERIALS**

Foam Core Art Board

[Office Depot](#) #642135

**ASSEMBLY**

**STEP 1:** Print templates onto legal size paper.

**STEP 2:** Trace templates onto hardboard.

**STEP 3:** Cut out notches where indicated.

**STEP 4:** Align notches and tap into place as shown in picture above with a hammer. **CAUTION**, use a piece of scrap lumber to tap on so you don't damage the edges.

**NOTE:** You will need three 14" x 5" pieces and five 9 1/2" x 5" pieces of hardboard for each set of dividers.



Questions or Comments?

[david@udfrag.com](mailto:david@udfrag.com)

